



## RECOMMENDED REPLACEMENT SEATS

CATERPILLAR Pipe layer					
MODEL	OPTION 1	OPTION	OPTION 3 (Air Option)	OEM SEAT	Comments
561M	1420	4020	4050 or 4060	Sears/CAT Contour	Installation kit SA19236.901 required. This kit accommodates all bolt patterns up to 355 wide x 402mm (14 x15.8").
572R	1420	4020	4050 or 4060	KAB	Installation kit SA19236.901 required. This kit accommodates all bolt patterns up to 355 wide x 402mm (14 x15.8").
583R	1420	4020	4050 or 4060	KAB	Installation kit SA19236.901 required. This kit accommodates all bolt patterns up to 355 wide x 402mm (14 x15.8").
589	1420	4020	4050 or 4060	KAB	Installation kit SA19236.901 required. This kit accommodates all bolt patterns up to 355 wide x 402mm (14 x15.8").